

1. INTRODUCTION

We wish to thank you for purchasing an AIRGANGWAY. AIRGANGWAY is an innovative product designed and studied in detail and tested to be able to hold a static load of 150 kg.

This ensures maximum safety and stability during the passage of one person at a time, exclusive purpose for which the bridge has been designed.

Before using your new AIRGANGWAY please carefully read this manual, where you'll find valuable information on inflation, use and maintenance.

2. PACKAGE CONTENTS

- 1 Bag transport.
- 1 Inflatable Gangway.
- 2 Supports.

3. INFLATION

Spread the gangway upside down.

Place the two mounting in the slots by passing the straps above the 2 columns.

Connect the inflator supplied with a 12V battery according to the polarity and select the pressure to 950 mbar.

Insert the tube into the inflation valve and press the "ON" position.

When the correct pressure inflator will automatically shut off.

Use ONLY the provided inflator.

The use of different compressors could cause the explosion of the gangway and void the warranty.

4. INSTALLING THE BUSHING

In order to ensure proper support of the gangway, and its stability during transit passenger, you must place the bushing not less than 30 cm away from the edge of the platform.

5. POSITIONING THE GANGWAY

Place the gangway between the stern platform and the dock. Then insert the locking pin into the socket located on the same platform.

The difference in height between the boat and the dock MUST NOT exceed 50 cm. Do anyway so that tampons support it at least 30 cm from the edge of the quay.

Verify that the oscillation of the vessel does not cause loss of footing the gangway from the quayside.

It is the responsibility of the commander to verify the correct positioning of the gangway and the inflation pressure before allowing the use of other crew members. Given the sensitivity of the walkway to the wind and possible variations of tide or other unforeseeable events you should not leave it mounted when it is not needed.

The gangway is designed to allow the transit between the boat and the dock of one person at a time normally walking.

Any other use, other than that indicated, is considered NOT ALLOWED and may absolve the manufacturer from any liability.

It's NOT ALLOWED to transit the gangway with suspension set to the topping lift.

6. MAINTENANCE

Your AIRGANGWAY is built with the best materials.

For proper maintenance it is recommended to wash it with fresh water and let it dry before storing it into the bag.

During the long periods of inactivity store it outspread and a bit inflated in a dry place to prevent mold. Stains can be removed with an ordinary detergent for rafts.

7. WARRANTY

Your AIRGANGWAY is guaranteed for a period of 24 months from the date of purchase proved by a valid receipt. The warranty covers the replacement and / or repair, free of charges, of the product or parts of it resultant defective at the origin, at the sole discretion of the manufacturer. Transport costs are to be charged to the customer.

The guarantee is void in case of negligence, neglect or abuse of the AIRGANGWAY.

We accept no responsibility for damage to persons or property which may arise directly or indirectly from failure to observe the instructions given in this manual.

8. CONFORMITY

We declare that the AIRGANGWAY with serial number:

AIG	#		#	
------------	----------	--	----------	--

has passed the quality control and complies with the standards of production required.

Translations in other languages are on the website.



www.airgangway.com info@airgangway.com
MarlinBoat srl Via Galvani 2 22070 Luisago COMO

AIRGANGWAY is a patented product.



Operation and maintenance manual

INDEX

1. Introduction
2. Package Contents
3. Inflation
4. Installing the bushing
5. Positioning of the gangway
6. Maintenance
7. Warranty
8. Conformity